



APRIL 2010 UK GBP LIST PRICE EX VAT
 PANTHER BROADCAST
 www.idx-europe.co.uk

TRIPOD SYSTEMS		
Systems 75mm		
ST4000	System T4 with T4 + A75/1 + S75 + Bag 75/1	£1,415.00
ST6000	System T6 with T6 + C75/2 + S75 + Bag 75/2	£2,238.00
ST6001	System T6 Alu with T6 + A75/1 + S75 + Bag 75/1	£1,615.00
Systems 100mm		
SX1000	System T10 with T10 + C100/1 + S100 + Bag 100/1	£4,395.00
SX1500	System X15 with X15 + C100/2 + MF100 + Bag 100/2	£6,025.00
Systems 150mm		
ST2800	System T28 with T28 + C150/1 + S100 + Case T28 + Bag 150/1	£8,820.00
ST4500	System T45 with T45 + C150/1 + S100 + Case T45 + Bag 150/1	£9,675.00
FLUID HEADS AND ACCESSORIES		
Fluid Heads		
149415	T4 Fluid Head up to 4kg, 75mm Ball, incl. Pan Bar, Camera Plate S	£720.00
149416	T6 Fluid Head up to 6kg, 75mm Ball, incl. Pan Bar, Camera Plate S	£995.00
149417	T10 Fluid Head up to 10kg, 100mm Ball, incl. Pan Bar, Camera Plate M	£2,605.00
149418	X15 Fluid Head up to 15kg, 100mm Ball, incl. Pan Bar, Camera Plate M	£3,624.00
156010	T28 Fluid Head up to 30kg, 150mm Ball, incl. Pan Bar, Camera Plate L	£6,475.00
149419	T45 Fluid Head up to 45kg, 150mm Ball, incl. Pan Bar, Camera Plate L	£7,565.00
Accessories		
149434	Camera Plate S for T4, T6	£66.50
149435	Camera Plate M DV for T10, X15	£103.00
149435	Camera plate M for T10, X15	£85.00
149436	Camera Plate L for T28, T45, L40	£115.00
155421	Camera Screw 1/4" for T4, T6, T10, X15	£10.00
155420	Camera Screw 3/8" for T10, X15, T28, T45, L40	£12.00
149439	Flange for Eye Piece Extension for X15, T28, T45	£90.00
150173	Pan Bar, S for T4,T6	£145.00
150172	Pan Bar, M Right for T10, X15 (also T28, T45 and L40)	£305.00
155172	Pan Bar, M Left for T10, X15 (also T28, T45 and L40)	£305.00
155185	Pan Bar Front Part, L Right for T28, T45, (also T10, X15)	£357.00
155186	Pan Bar Handle, L Right for T28, T45, (also T10, X15)	£357.00
158846	Pan Bar Front Part, L Left for T28, T45, (also T10, X15)	£320.00
158847	Pan Bar Handle, L Left for T28, T45, (also T10, X15)	£320.00
TRIPODS AND ACCESSORIES		
Tripods 75mm		
149400	A75 / 1 Tripod Aluminium, Single Stage	£335.00
149401	C75 / 1 Tripod Carbon Fibre, Single Stage	£665.00
149402	C75 / 2 Tripod Carbon Fibre, Two Stage	£960.00
Tripods 100mm		
149403	Tripod C100/1-Long, Carbon Fibre, Single Stage	£1,135.00
161798	Tripod C100/1-Short, Carbon Fibre, Two Stage	£1,150.00
149404	Tripod C100/2, Carbon Fibre, Two Stage	£1,565.00
Tripods 150mm		
162717	Tripod C 150/1HD-Long, for Carbon Fibre Single Stage	£1,595.00
170810	Tripod C 150/1 HD-Medium, for Carbon Fibre, Single Stage	£1,575.00
161624	Tripod C 150/1 HD-Short, for Carbon Fibre, Single Stage	£1,548.00
149407	Tripod C 150/2 HD, Carbon Fibre, Two Stage	£1,810.00
Tripods Mid-Level Spreaders		
149409	Mid-Level Spreader & Rubber Feet MF75, for 75mm Tripod	£760.00
161966	Mid-Level Spreader M75, for 75mm Tripod	£700.00
164488	Rubber Feet F75 (3 pieces), for 75mm Tripod	£66.00
165342	Mid-Level Spreader & Rubber Feet MF100/150, for 100/150mm Tripods	£920.00
165341	Mid Level Spreader M100/150 S, for 100/150mm Tripods	£715.00
149411	Rubber Feet F 100/150, for 100/150mm Tripods	£359.00
149413	Mid-Level Spreader and Rubber Feet MF 100/150, for 100/150mm Tripods	£780.00
149412	Mid Level Spreader M100/150 S, for 100/150mm Tripods	£575.00
171239	Mid Level Spreader M 100/150, Short for 100/150mm Tripods	£520.00
Tripods - Ground Spreaders		
149408	Ground Spreader S75	£121.00
149410	Ground Spreader S100/150	£399.00
159062	Ground Spreader SD 100/150	£1,082.00
169455	Ground Spreader SD 100/150 Short	£1,070.00
Tripods - Castors		
149424	Dolly SD 100/150	£1,485.00
149414	Dolly D75	£187.00
149059	Universal Dolly (without wheels) for Tripods, Pixy	£1,203.00
169445	Studio Wheel with Cable Guard for Universal Dolly (3 pcs.=1 Set)	£115.00
169460	Adjusting Star for Dolly SD 100/150 with Screw	£78.00
150473	Rubber Foot for Universal Dolly (1 pcs) 3pcs = 1set	£158.00
110391	Levelling Foot for Universal Dolly (1 pcs) 3pcs = 1set	£79.00
BAGS AND CASES		
Bags and Cases		
149426	Bag for T4, T6 + C75/1 for T4 + C75/1 or T6 + C75/1	£272.00
149427	Bag for T4, T6 + C75/2 for T4 + C75/2 or T6 + C75/2	£254.00
149428	Bag for T10, X15 + C100/1 for T10 + C100/1 or T10 + C100/1	£375.00
149429	Bag for T10, X15 + C100/2, C100/X for T10 + C100/2 or T10 + C100/2	£366.00
149430	Bag for C150/1 for C150/1	£435.00
149431	Bag for C150/2 for C150/2	£423.00
149432	Case for T28/45 for T28 or T45	£448.00

ROLLER PLATE PACKAGES		
Roller Plate Economy		
Package includes Roller Plate and Handle, Tire Set (157041), adjustable Bazooka with integrated 75/100mm Bowl (138733), Seat (122149) and Seat Extension (105660 + Bolt 142310)		£3,625.00
Roller Plate Standard		
Package includes Roller Plate and Handle, Tire Set (157041), 2 additional Twin Tires (2 x 155493), Gas Spring Bazooka (147496), Seat (122149), Seat Extension (105660 + Bolt 142310) and 100mm Bowl (100383 + 107375)		£5,100.00
Roller Plate Golden		
Package includes Roller Plate and Handle, additional Roller Plate (139564), Tire Set (157041), 2 additional Twin Tires (2 x 155493), Gas Spring Bazooka (147496), Single Seat Turnstile (146708), Seat (122149), Seat Extension (105660 + Bolt 142310) 100mm Bowl (100383 + 107375) and Case (143951)		£7,250.00
HUSKEY Dolly PACKAGES		
Husky Dolly Economy		
Package includes Husky Dolly with Air Tires (138576)		£4,658.00
Husky Dolly Standard		
Package includes Husky Dolly with Air Tires (138576), Gas Spring Bazooka (147496), Single Seat Turnstile (147496), 100mm Bowl (100383 + 107375), Seat (122149), Seat Extension (105660)		£7,450.00
Husky Dolly Golden		
Package includes Husky Dolly with Air Tires (138576), 2 additional Twin Tires (138579), HD Gas Spring Bazooka (107028), Two Seat Turnstile (100374), 100mm Bowl (100383 + 107375), 2 Seats (2 x 122149) and Seat Extensions (105660 + 105662 + 105661 105661 + 100395)		£9,750.00
BROADCAST PRODUCTS		
Roller Plate		
139564	Roller Plate	£1,016.00
157041	Tire Set for Roller plate	£1,634.00
155493	Twin Wheel for Roller Plate Tire Set	£121.00
139846	Studio Wheel for Roller Plate (4pcs.=1set)	£73.00
138609	Platform Rear	£260.00
143797	Tripod Spider for Husky/Roller Plate (1leg)	£454.00
139639	Push Bar	£351.00
143909	Roller plate Accessories Box	£599.00
143951	Case for Roller Plate	£545.00
122209	Euroadapter for Connector Plate	£128.00
Husky Dolly		
138576	Husky Dolly with Pneumatic Wheels incl. Telescopic Steering Shaft	£4,658.00
138579	Twin Wheel	£55.00
139645	Studio Wheel Husky Dolly	£109.00
138609	Platform Rear	£260.00
138696	Platform Left	£284.00
138605	Platform Right	£284.00
139639	Push Bar	£350.00
143797	Tripod Spider for Husky/Roller Plate (3 pcs = 1 set)	£454.00
155433	Husky Crane axles kit inclusive of a Tripod Spider	£708.00
Multi-Mount		
145990	Multi-Mount	£1,512.00
100559	Bag for Multi-Mount	£109.00
145993	Suction Cup for Multi-Mount	£290.00
150553	Multi-Mount Universal Clamp	£139.00
143082	Rotating Plate for Camera	£478.00
145996	Multi-Mount Rod 30cm (1ft.)	£48.00
145995	Multi-Mount 46cm (1.5ft.)	£52.00
157196	Multi-Mount 60cm (2ft.)	£55.00
Romy Lights		
139871	Romy 20/50 W / 12V with Diffusion Filter, XLR Plug, Focusable	£224.00
139872	Romy 20/50 W / 12V with Diffusion Filter, A/B Plug, Focusable	£254.00
139873	Romy 75 W / 12V Dimmable XLR Plug with Diffusion Filter, XLR Plug, Focusable	£272.00
139874	Romy 75 W / 12V Dimmable A/B Plug with Diffusion Filter, A/B Plug, Focusable	£296.00
155792	Romy 100 W Mains Light with Diffusion Filter and Dimmable Trafo, Focusable	£357.00
155808	Romy 100 Light Set with Bag 3 x Light with Trafo, Doors, Bulb, Stand, Gels	£1,512.00
139876	Dichroic Filter for ROMY	£49.00
100125	Set Gel Filter (3x3pcs.)	£23.00
139875	4 leaf Barndoor for ROMY	£62.00
169387	Cable Extension XLR 4 pin 2m /6' 7"	£79.00
159929	Cable Extension XLR 4 pin 5m /16' 5"	£103.00
155975	Bag for ROMY 100 Light Set	£133.00
001B-0312	Stand for Romy 100W	£85.00
149036	Adapter Cable with A/B Socket to XLR Plug	£120.00
149037	Adapter Cable with XLR Socket to A/B Plug	£120.00
156642	Ball Joint	£91.00
155271	Romy Grip	£30.00
140253	75W Socket Housing Modification Kit XLR (without Camera Mount/Screw)	£169.00
141969	75W Socket Housing Modification Kit A/B (without Camera Mount/Screw)	£199.00
139877	Bulb 20 W	£6.00
139888	Bulb 35W	£6.00
139878	Bulb 50w	£6.00
139879	Bulb 75 W	£7.50
155807	Bulb 100 W	£10.90
139868	Electronic Belt 13.2V /9.5Ah	£859.00
Broadcast Tracks (Plastic/Alu)		
138707	Plastic Track 1.5m/5', 1pc. (2pcs. required for a set)	£91.00
138847	Track Curve Outside 62cm / 2' Track Gauge	£206.00
143066	Track curve Outside 36cm / 1' 2" Gauge	£194.00
138731	Track Inside Curve	£188.00
139887	Bag for 6 pairs of Track or 4 pairs of Curves	£73.00
144206	Sleeper for Plastic Track	£103.00
Broadcast Track Wheels		
138590	Track Wheel, Standard, Silicone (4pcs. required for a set)	£393.00
163047	Track Wheel, Medium, VK92 (4pcs. required for a set)	£514.00
161636	Track Wheel, Curve	£496.00
4 X 2 Track Wheels		
100419	Track Wheel, 4 x 2 Standard (silicone), (4pcs. required for a set)	£750.00
162206	Track Wheel, 4 x 2 Medium, VK92 (4pcs. required for a set)	£799.00
103930	Track Wheel, 4 x 2 Hard (4pcs. required for a set)	£738.00

Seats		
100552	Seat Contour + Seat Belt	£810.00
130276	Seat Contour + Seat Belt Compact	£508.00
100387	Seat Contour, Compact	£284.00
122149	Eccentric Seat, Heat Insulated	£206.00
124881	Seat Cushion, Heat Insulated (Goretex)	£60.00
Seat Extensions		
105661	Seat Extension Combined 10cm	£133.00
105662	Seat Extension Combined 20cm	£145.00
105663	Seat Extension Combined 30cm	£157.00
105658	Seat Extension Vertical 10cm	£145.00
105659	Seat Extension Vertical 20cm	£157.00
105660	Seat Extension Vertical 30cm	£169.00
139847	Seat Tube 10cm	£42.00
139848	Seat Tube 20cm	£48.00
139849	Seat Tube 30cm	£55.00
142310	Connector Pin, Jammed	£115.00
100395	Connecting Pin	£24.00
Bazooka		
107025	Bazooka 10cm	£424.00
107026	Bazooka 20cm	£448.00
107030	Bazooka 30cm	£472.00
107027	Bazooka 40cm	£496.00
107029	Bazooka 50cm	£520.00
107028	Bazooka Two Stage, with Gas Spring Two Stage and Pneumatic Spring	£2,202.00
138733	Broadcast Adjustable Bazooka Single Stage, with 75/100mm Bowl Adapter	£478.00
147496	Broadcast Bazooka with Gas Spring Single Stage, with Pneumatic Spring, Euromount	£1,149.00
U-Bangi II		
108867	U-Bangi II, 90cm	£5,385.00
125128	U-Bangi II, 140cm	£5,748.00
121890	U-Bangi II, 200cm	£6,232.00
125127	U-Bangi II, 300cm	£7,563.00
125136	U-Bangi Tripod Pin (2pcs required for a set)	£303.00
AA120	Low Combo Tripod	£285.00
125137	Double Euroadapter	£242.00
125130	U-Bangi Track 1.4m (2pcs required for a set)	£1,053.00
121888	U-Bangi Track 2m (2pcs required for a set)	£1,295.00
125129	U-Bangi Track 3m (2pcs required for a set)	£1,960.00
108874	Case for U-Bangi II 90cm	£424.00
100579	Case for U-Bangi II 140cm	£557.00
100581	Case for U-Bangi II 200cm	£798.00
Wall Spreader		
138966	Complete Wall Spreader Set	£4,838.00
138930	Telescopic Pole Wall Spreader 140-250cm	£338.00
138960	Telescopic Pole Wall Spreader 215-400cm	£399.00
138963	Telescopic Pole Wall Spreader 315-600cm	£459.00
138949	Wall Spreader Tightening Element	£484.00
138934	Wall spreader Clamping Ring	£435.00
138940	Wall Spreader Double Clamping Ring	£266.00
138952	Wall Spreader Plastic Tube	£30.00
138953	Wall Spreader Extension Tube	£54.00
138927	Wall Spreader Buffer	£60.00
139045	Wall Spreader Clamping Ring with Euroadapter	£424.00
Low Boy (Hi Hat)		
140500	Low Boy (Hi Hat) without Bowl for lowest camera positions	£467.00
100383	Bowl 100mm	£182.00
107374	Bowl 150mm	£175.00
107837	Mitchell Plate	£182.00
107375	Bracket	£260.00
107407	Short Offset Bracket	£347.00
107406	Long Offset Bracket	£436.00
105581	Bowl Adapter 150-100mm	£103.00
108515	Banana Adapter (2pcs required for a set)	£61.00
100415	Combi Bowl Adapter	£1,694.00
106635	Mitchell 4-way Leveller	£1,694.00
Miscellaneous Accessories		
100447	Euroadapter Mount	£303.00
100374	Turnstile attachment, with intergrated Connecting Pin for 2 Seats	£1,439.00
146706	Turnstile attachment (1 Seat), with intergrated Connecting Pin for 1 Seat	£811.00
100448	Center Off	£714.00
136974	Mitchell-Euroadapter	£593.00
144888	Euro-Mitchell Adapter	£762.00
100512	Rotary Adapter	£1,452.00
122209	Euroadapter for Connector Plate	£127.00
100428	150mm Bowl-Euroadapter	£393.00
107104	Low Shot Plate	£242.00
126746	Combi Off-Set Bowl	£919.00
100429	Tool Kit	£314.00
100566	Case for Accessories	£544.00
AC1575B	Super Clamp	£31.00
Universal Dolly		
149059	Universal Dolly (without wheels)	£1,204.00
150473	Rubber Foot for Universal Dolly (3pcs required for a set)	£157.00
110391	Leveling Foot for Universal Dolly (3pcs required for a set)	£79.00
169445	Studio Wheel with Cable Guard (3pcs required for a set)	£115.00
122209	Euroadapter for Connector Plate	£127.00
Pixy Crane Versions		
139714	Pixy Crane Version 1, with Tripod, without Weights	£5,094.00
139713	Pixy Crane Version 2, with Tripod, without Weights	£7,375.00
139712	Pixy Crane Version 3, with Tripod, without Weights	£8,131.00
139711	Pixy Crane Version 4, with Tripod, without Weights	£9,583.00
139710	Pixy Crane Version 5, with Tripod, without Weights	£10,049.00
139709	Pixy Crane Version 6, with Tripod, without Weights	£11,677.00
137091	Pixy Crane Version 7, with Tripod, without Weights	£12,142.00
146675	Pixy Crane Version 1 Compact, with Tripod, without Weights	£5,439.00
146676	Pixy Crane Version 2 Compact, with Tripod, without Weights	£8,537.00
146677	Pixy Crane Version 3 Compact, with Tripod, without Weights	£9,320.00

Pixy Components		
138892	Pixy Tripod	£962.00
143788	Central Pivot Section Pixy crane	£1,876.00
137098	Mount Pixy	£1,204.00
137363	Lifting Rod Pixy	£103.00
Pixt Crane Cables		
137106	Base Bracing Pixy	£956.00
147795	Base Bracing Pixy, Studio	£1,513.00
157242	Wiring Extension Pixy, Version 3/5/7	£290.00
138383	Wiring Extension Pixy, Version 4	£835.00
138397	Wiring Extension Pixy, Version 6	£908.00
Pixy Crane Tubes		
143777	Carrier Tube Pixy, 150cm / 4' 11"	£871.00
146203	Carrier Tube Compact, 85cm / 2' 9"	£859.00
137097	Rear Tube Pixy 145cm /4' 9"	£787.00
146217	Rear Tube Compact 80cm/2' 7"	£774.00
137096	Extension Tube Pixy 145cm/4' 9"	£363.00
146168	Extension Tube Compact 80cm 2' 7"	£357.00
137342	Extension Tube for Bracing	£532.00
146200	Extension Tube for Bracing Compact	£532.00
Pixy Crane Balance Tubes and Rods		
156391	Balance Tube Kit Version 1	£702.00
156383	Balance Tube 0.3m	£163.00
157031	Balance Tube 0.65m	£169.00
156147	Balance Tube 1.3m	£175.00
156330	Balance Tube Support	£115.00
142404	Balance Tod 1.6m	£109.00
146128	Balance Tod Compact 1.6m	£194.00
142405	Balance Rod 1.3m	£103.00
146205	Balance Rod Compact 1.3m	£188.00
142406	Balance Rod Support	£85.00
Pixy Crane Weights		
115415	3kg Weight	£115.00
115431	5kg Weight	£133.00
115432	7kg Weight	£151.00
139692	17kg Counterweight	£91.00
114191	8kg Variable Counter Weight	£236.00
104378	15kg Counter Weight	£115.00
139702	Fine Adjustment Counter Weight	£436.00
142297	Weight Bar, Diameter 25mm / 1"	£181.00
Pixy Crane Accessories		
139313	Pixy Adapter for Euromount	£375.00
141172	Pixy Adapter for Foxy Pyramid	£593.00
140241	Pixy Monitor Holder	£278.00
143082	Rotating Plate for Camera	£478.00
100383	Bowl 100mm	£181.00
107374	Bowl 150mm	£175.00
107407	Short Off Set Bracket	£357.00
122209	Euroadapter for Connector Plate	£127.00
Pixy Crane - Special Remote Head Accessories		
100020	Pixy Adapter for Remote Head Control	£793.00
155416	Pixy Jimmy Jib Adapter	£223.00
156712	Pixy Cammate Adapter	£351.00
141548	3/8" Distance Bolt for Servo Box	£15.00
M323	Quick Change Rect. Plate Adapter	£24.00
104110	Turning Lock for QCRPA Grub Screw	£1.25
142295	Distance Adapter for QCRPA	£54.50
159478	CamMate Off-Set Bowl Adapter	£229.00
Pixy Crane - Transportation		
100584	Case for Pixy Crane Versions 1-7	£1,186.00
100586	Case for Pixy Crane Compact v.1-3	£944.00
100585	Bag for Pixy Crane	£460.00
100587	Bag for Pixy Crane Compact, Version 1-7+Tripod	£436.00
109018	Counter Weight Cart	£393.00
ACCESSORIES AND ADAPTORS		
Accessories and Adaptors		
126746	Combi Offset Bowl	£919.00
105581	Bowl Adapter 150mm/100mm to use 100mm heads on 150mm bowl	£103.00
100428	150mm bowl - Euroadapter Euro Adapter for 150mm bowl	£393.00
107104	Low shot plate reverses the camera in underslung	£242.00
136794	Mitchell Euroadapter	£593.00
144888	Euro Mitchell Adapter	£762.00
100512	Rotary Adapter	£1,452.00
139714	Pixy Crane version 1 with tripod but no weights	£4,960.00
138892	Tripod Pixy	£961.00
136728	Vario Jib (no weights)	£6,715.00
135606	Multi Rig	£1,452.00
136756	Euro Adapter for Multiring	£115.00
140688	Fine Adjustment Weight for Vario	£387.00
100402	Jib Offset Rig	£357.00

Terms & Conditions:

- 1/ All prices in GBP, ex-works Langley UK, excluding VAT
- 2/ Prices & specifications subject to change without notice
- 3/ IDX acknowledges all manufacturers trademarks as property of their respective owners